

RWY 07/25

TWR - 118.2 / 122.2
APP - 119.2 (CLARK)
ACC - 120.5 / 119.3 (CENTRAL NORTH)
- 132.7 / 118.9 (CENTRAL WEST)



DEPARTURE ROUTE DESCRIPTION

SID	TAKE-OFF	PROCEDURE	REMARKS
ARITA2A	RWY 07 - Left turn within 3.0 NM to SBA DVOR/DME	Track-out and climb outbound on SBA DVOR/DME Radial 193. Reverse course and track-in on SBA DVOR/DME via Radial 193 to cross SBA DVOR/DME at or above 4000 FT. Track-out on SBA DVOR/DME Radial 051 to ARITA to cross D10.0 SBA DVOR/DME FIX at or above 7000 FT.	
ARITA2B	RWY 25 - Left turn to SBA DVOR/DME		
EXOLO2A	RWY 07 - Left turn within 3.0 NM to SBA DVOR/DME	Track-out and climb on SBA DVOR/DME Radial 208 to cross EXOLO at or above FL140.	
EXOLO2B	RWY 25 - Left turn to SBA DVOR/DME		
KIBOK2A	RWY 07 - Left turn within 3.0 NM to SBA DVOR/DME	Track-out and climb outbound on SBA DVOR/DME Radial 193. Reverse course and track-in on SBA DVOR/DME via Radial 193 to cross SBA DVOR/DME at or above 4000 FT. Track-out on SBA DVOR/DME Radial 041 to KIBOK to cross D10.0 SBA DVOR/DME FIX at or above 7000 FT.	
KIBOK2B	RWY 25 - Left turn to SBA DVOR/DME		
NATIB2D	RWY 07 - Left turn within 3.0 NM to SBA DVOR/DME	Track-out and climb outbound on SBA DVOR/DME Radial 193. Reverse course and track-in on SBA DVOR/DME via Radial 193 to cross SBA DVOR/DME at or above 4000 FT. Track-out on SBA DVOR/DME Radial 112 to cross NATIB at or above 6000 FT.	
NATIB2E	RWY 25 - Left turn to SBA DVOR/DME		
SILAG2A	RWY 07 - Left turn within 3.0 NM to SBA DVOR/DME	Track-out and climb on SBA DVOR/DME Radial 222 to OLONG. Continue climb so as to cross KARAG at or above 7000 FT. Turn right and track-out MIA DVOR/DME Radial 269 to SILAG.	
SILAG2B	RWY 25 - Left turn to SBA DVOR/DME		
SIMBO2D	RWY 07 - Left turn within 3.0 NM to SBA DVOR/DME	Track-out and climb outbound on SBA DVOR/DME Radial 193. Reverse course and track-in on SBA DVOR/DME via Radial 193 to cross SBA DVOR/DME at or above 4000 FT. Track-out on SBA DVOR/DME Radial 085 to cross SIMBO at or above 6000 FT.	
SIMBO2E	RWY 25 - Left turn to SBA DVOR/DME		
SUMIX2A	RWY 07 - Left turn within 3.0 NM to SBA DVOR/DME	Track-out and climb on SBA DVOR/DME Radial 190 to cross SUMIX at or above 6000 FT.	
SUMIX2B	RWY 25 - Left turn to SBA DVOR/DME		
VILAR2A	RWY 07 - Left turn within 3.0 NM	Track-out and climb outbound on SBA DVOR/DME Radial 193. Reverse course and track-in on SBA DVOR/DME via Radial 193 to cross SBA DVOR/DME at or above 4000 FT. Track-out on SBA DVOR/DME Radial 007 to cross D10.0 SBA DVOR/DME FIX at or above 8000 FT. Continue climb to cross VILAR at or above FL090.	
VILAR2B	RWY 25 - Left turn to SBA DVOR/DME		
VILAR2C For high performance aircraft	RWY 07 - Left turn within 3.0 NM	Intercept and track-out on SBA DVOR/DME Radial 007 to cross D10.0 SBA DVOR/DME FIX at or above 8000 FT. Continue climb to cross VILAR at or above FL090.	
VILAR2D For high performance aircraft	RWY 25 - Right turn		